

Economy Pressure Regulator

Twin Stage

General Purpose
Non-corrosive
High inlet pressure
Precise outlet pressure

Specifications

Materials

Body: Brass
Bonnet: Brass
Second Stage Diaphragm:
Neoprene

Pressure Rating

Maximum inlet pressure

Connections

Inlet: Available with most cylinder connections; eg BS3, BS4

Outlet: Hose tail is standard, compression fittings can be specified.



This series of brass two-stage regulators are designed for use with non-corrosive gases and have a pre-set first stage feeding an adjustable second stage. The large diameter of the second stage diaphragm ensures that the pressure control is extremely precise. The two-stage design means a constant outlet pressure is maintained regardless of the cylinder pressure.

Ordering Information

Order Code	Model Type	
17/2004	0-0.5 Bar	Outlet Pressure
17/2005	0-2 Bar	Outlet Pressure
17/2022	0-5.5 Bar	Outlet Pressure
17/2006	0-10 Bar	Outlet Pressure

Special Gases and Mixtures

CryoService

Gases for Science, Leisure and Industry

CryoService Limited, Warrdon Business Park, Worcester WR4 9RH
Tel: 01905 758200 Fax: 01905 754060
Email: info@cryoservice.co.uk www.cryoservice.co.uk

